

# GRS-H 15/25/30/40/50/60/75/90/120A

ULTRA-COMPACT STATIC POWER UNITS WITH DC / AC LOGIC CONTROL

#### MAIN APPLICATIONS

- Extrusion, injection, blow moulding, thermoforming of plastics
- · Vulcanization of rubber
- Synthetic fibre production and polymerisation
- Packing and packaging
- Dryers for ceramics and building elements
- Industrial electric ovens
- · Food processing plants
- · Chemical and pharmaceutical industry





#### MAIN FEATURES

- Ultra-compact dimensions from 15A to 120A
- · DIN rail and panel mounting
- · Switching at zero voltage changeover
- Input command from DC/AC logic signal with push-in connectors; signalling leds
- Cage clamps for power cables
- Load voltage 480V, 600V AC
- SCCR 100 kA
- Thermal alarm option with led and alarm output
- Interrupted load option with led and alarm output
- · Internal overvoltage protection

# PROFILE

Correct management of electrical heating elements for industrial heating applications

requires robust, safe, interference-free, fast and diagnostically capable static contactors.

The range of static contactors with GRS-H heatsink meets all these requirements, with current ratings from 15 to 120 Amperes and voltages up to 600 V AC, with extremely compact size in every single current level. The thermal design of all models guarantees the continuous supply of the rated current at an ambient temperature of 40°C through high efficiency heat sinks, assisted by fans for the 90A and 120A models.

The derating curves show how higher current values can also be achieved, at lower temperatures, and illustrates the possibility of mounting various devices packed together on the DIN rail.

# GRS COMMAND SIGNAL CONNECTION

The GRS-H series can be controlled by DC and AC logical signals managed through push-in connectors for a faster and easier connection, even without tools.

The ON / OFF status of the static device is always displayed by a green

LED on the front panel, for an immediate view of its operation.

#### POWER CONNECTIONS

Both the line voltage terminal available on the upper part of the device and the load terminal on the lower part are of the "cage" type, which offers the best and safest seal even for cables of different cross-sections, whether mounted with a cable lug or simply stripped.

#### DIAGNOSTICS AND ALARMS

It is increasingly vital for operators and maintainers to recognize possible anomalies in the system immediately and solve them quickly in order to ensure the efficiency and profitability of machinery and plants. The GRS-H series offers a series of diagnostic information associated with a physical alarm output with voltage-free or PNP-type isolated contact.

The thermal alarm is triggered if heat dissipation exceeds a critical threshold, signalling it with a yellow led on the front panel, interrupting the power supply and triggering the alarm output (NO or NC). This function is available for all sizes as an option.

The absence of current on the load (for models with DC control) is indicated by a red led on the front panel and by the activation of the alarm output, as well as by the absence of line voltage.

Alarm output status is memorized: in the presence of a 24 V DC auxiliary power supply, the alarm will be memorized even in the event of an OFF command.

The alarm is reset when normal operating conditions are restored, or when the 24 V DC auxiliary power supply is switched off and on again.

#### TECHNICAL DATA MAIN FEATURES

Category of use: AC51 Rated working voltage - 480Vac (max. range 24...530Vac) - 600Vac (max range 24 ... 660Vac) Rated frequency: 50/60Hz Non-repetitive voltage:

 ì1200Vp for model with rated voltage 480Vac

 1400Vp for model with rated voltage 600Vac

Switching voltage for zero: < 20V Activation time: = 1/2 cycle Deactivation time: = 1/2 cycle Potential drop at rated current: = < 1.2Vrms Power factor = 1

#### **C**ONTROL INPUT

- DC INPUT Type " D/DD-0 ": Max. input: < 9mA @32V Max. reverse voltage: 36Vdc Control voltage: 5,1...32Vdc Activation voltage: > 5,1Vdc Deactivation voltage:< 5Vdc Input impedance 500 kΩ

### Type " D-1/2/3/5 ":

Power supply (range from 6 to 32 Vdc. Imax < 14 mA at 32V) GRS-H-90..120A-..FAN63: Power supply GRS-H + Fan(Range from 20 to 27 Vdc, Imax <150mA at 24V with Fan active) Max. reverse voltage: 36Vdc

Maximum control signal current absorption: <3.2mA @32V Control voltage: 3...32Vdc Activation voltage: > 3Vdc Deactivation voltage:< 1,8Vdc Input impedance 9,45 kΩ

- AC INPUT (Type "A"): Control voltage: 20...260 Vac/Vdc INSTALL FUSE (3A MAX) ON THE CONTROL INPUT CIRCUIT Activation voltage: > 15Vac/Vdc Deactivation voltage: < 6Vac/Vdc Current draw: <= 8 mAac/dc @ 260 Vac/Vdc

#### **ALARM OUTPUT OPTION**

(Type "D" Input Version) A load or line failure or an overtemperature alarm commands:

- Options 1/2/5: one voltage-free contact (solid state N.C or N.O.), max. properties:
- N.O. version 30V-150mA conduction resistance:  $\leq 1\Omega$
- N.C. version 30V-50mA conduction resistance:  $\leq 15\Omega$
- Option 3: two normally inactive (par-

allelable) PNP digital outputs, one for load failure and the other for overtemperature (properties: Imax =150mA Vout= + V DC power supply -1V).

Maximum interrupted load alarm trip delay < 400ms

# **ALARM OUTPUT OPTION**

(Type "A" Input Version) The over-temperature alarm commands a voltage-free contact (solid state N.C.), max. properties: 30V-50mA conduction resistance: ≤ 15 Ω

# **OUTPUTS**

### **GRS-H 15**

Rated current: 15 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 620A l2t for blowout: ≤ 1800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 25**

Rated current: 25 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 620A I2t for blowout:  $\leq$  1800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 25I**

Rated current: 25 A@40°C in continuous service Non-repetitive overcurren t=20 ms: 1600A I2t for blowout: ≤ 12800A2s dV/dt critical with output deactivated: 1000V/µs

#### **GRS-H 30**

Rated current: 30 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 620A I2t for blowout: ≤ 1800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 30I**

Rated current: 30 A@40°C in continuous service Non-repetitive overcurrent t=20 ms: 1600A I2t for blowout: ≤ 12800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 40**

Rated current: 40 A@40°C in continuous service

Non-repetitive overcurrent t=20 ms: 620A

I2t for blowout: ≤ 1800A2s

dV/dt critical with output deactivated: 1000 V/µs

#### **GRS-H 50**

Rated current: 50 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1600A I2t for blowout: ≤ 12800A2s dV/dt critical with output deactivated: 1000V/µs

#### **GRS-H 60**

Rated current: 60 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1600A I2t for blowout:  $\leq$  12800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 75**

Rated current: 75 A@ 40°C in continuous service Non-repetitive overcurrent t=20 ms: 1600A I2t for blowout: ≤12800A2s dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 90**

Rated current: 90A@ 40°C in continuous service (complete with specified fan) Non-repetitive overcurrent t=20 ms: 1500A I2t for blowout:  $\leq 11250A2s$ dV/dt critical with output deactivated: 1000V/µs

# **GRS-H 120**

Rated current: 120A@ 40°C in continuous service (complete with specified fan)

Non-repetitive overcurrent t=20 ms: 1500A

I2t for blowout: ≤ 11250A2s

dV/dt critical with output deactivated: 1000V/uS

# THERMAL PROTECTION

(Optional, always present in GRS-H with current size  $\geq$  50A):

The temperature of the SCR module is constantly monitored inside the device.

When the maximum temperature threshold of the internal SCR is exceeded, current conduction to the load is interrupted and the yellow thermal protection LED comes on to signal the condition.

# **I**SOLATION

Rated isolation voltage input/output: 4000VACrms 1min

#### **AMBIENT CONDITIONS**

• Working temperature: from 0 to 80°C (according with heat sink curves)

- Max. relative humidity: 90% noncondensing at 40°C
- Max. installation altitude: 6600ft
   above sea level
- Pollution level : 2
- Storage temperature: -20..+85°C

# SOLID STATE RELAY DISSIPATED POWER CALCULATION

Single-phase relay Pd = 1.2 \* IRMS [W]

IRMS = single-phase load current

#### INSTALLATION NOTES

Use the extra-rapid fuse shown in the catalogue according to the connection example supplied.

Applications with static units must also include a safety circuit breaker for disconnecting the power line from the load.

To obtain high reliability of the device, it is essential to install it correctly inside the panel in order to obtain adequate heat exchange between the heat sink and the surrounding air under conditions of natural convection.

Mount the device vertically (maximum 10° inclination from the vertical axis)

- Vertical distance between a device and the panel wall >50mm
- Horizontal distance between a device and the panel wall at least 20mm
- Vertical distance between one device and another at least 50mm.
- Horizontal distance between one device and another at least 20mm (in the event of installation at shorter distances, see derating curves).

Make sure that the cable ducts do not reduce these distances; in this case, mount the units overhanging the panel, so that the air can flow vertically on the heat sink without hindrance.

#### LIMITS OF USE

- Ambient temperature limits, depending on derating curves.
- Need for air exchange with the outside or an air conditioner to transfer the dissipated power to the outside of the panel.
- Installation limits (distances between devices to ensure dissipation under natural convection conditions)
- Maximum voltage limits and derivative of the transients present on the line, for which the static unit provides internal protection devices (depending on the models).
- Presence of leakage current < 3mA (max. value with nominal voltage and junction temperature of 125°C).

#### DIMENSIONS AND MOUNTING MEASUREMENTS











90-120A



Model	15-25A	30A	40-50A	60-75A	90-120A
Weight [g]	194	237	388	688	796

Notes: The dimensions are representative of all models of the series (command "D" type, "A" type and with options)





NOTE: For the GRS-H 90A version without a fan, fixing with panel screws is not provided.

#### **DESCRIPTION OF CONNECTIONS**



	Power te	rminals (common to all versions) (Overv	oltage Category III)		
Rif.	Description		Notes		
1/L1	Line Connection				
2/T1	Load Connection				
	Signal connector	version without options (GRS-HD-0) (C	vervoltage Category II o III)		
3/A2-	GND Control input ON/OFF	Control input ground			
4/A1+	+Vdc control input ON/OFF	Range from 5,1 to 32 Vdc, Imax <9 mA at	32V OFF < 5V Input impedance 500 k $\Omega$		
	Signal connector	version without options (GRS-H…DD-0) (	Overvoltage Category II o III)		
3/A2-	GND Control input ON/OFF	Control input ground			
4/A1+ Range from 5,1 to 32 Vdc, Imax <9 mA at 32V OFF< 5V					
5/A1+	+Vdc Control input ON/OFF	Input impedance 500 kΩ			
6/A2-	GND Control inputON/OFF	Control input ground			
	Signal connector version	with options "1 " and "2 " type (GRS-HD-1/2) (Overvoltage Category II o III)			
3/A2-	GND for power supply and control input ON/OFF	Ground for power supply and control input	ON/OFF		
		Power supply GRS-H (Range from 6 to 32			
4/Us	+ Vdc power supply	GRS-H-90120AFAN63: Power supply ( (Range from 20 to 27 V DC, Imax <150 m/			
5/A1+	+Vdc control input ON/OFF	Range: ON from 3 to 32Vdc, Imax <0,5 m/	A at 32V OFF< 1,8V Input impedance 9,45 k $\Omega$		
6/A2-	GND Control input ON/OFF (common to terminal 3/A2-)	Additional connection to be used only as GND for the control signal			
		Version with option 1	Version with option 2		
7/AL	Alarm output:	Solid state N.O. contact	Solid state N.C. contact		
8/AL	<ul> <li>Interrupted load</li> <li>Line voltage absent</li> </ul>	Imax =150mA Vmax = 30 V DC/25V AC Z closed < 1 Ω	Imax = 50mA Vmax = 30 Vdc/25Vac Z closed < 15 $\Omega$		
	- Overtemperature	$Z_{open} > 1 M\Omega$	$Z_{open} > 1 M\Omega$		

For terminals and conductors to be used, see the table: "CLAMP AND CONDUCTOR CHARACTERISTICS TABLE" on page 14

# **DESCRIPTION OF CONNECTIONS**



Signal connector version with option type "3" (GRS-HD-3) (Overvoltage Category II o III)								
Rif.	Description	Notes						
3/A2-	GND for power supply and control input ON/OFF	Ground for power supply and control input ON/OFF						
		Power supply GRS-H (Range from 10 to 32 Vdc, Imax < 14 mA a 32V)						
4/US	+ Vdc power supply	GRS-H-90120AFAN63: Power supply GRS-H + Fan (Range from 20 to 27 V DC, Imax <150 mA at 24V with Fan active)						
5/A1+	+Vdc control input ON/OFF	Range: ON da 3 a 32Vdc, Imax <0,5 mA a 32V $$ OFF< 1,8V Input impedance 9,45 k $\Omega$						
6/TA	Overtemperature alarm output	PNP output normally not active (1) Imax =150mA Vout = + V DC power supply -1V						
7/FA Alarm output: interrupted load or line voltage absent PNP output normally not active (1) Imax =150mA Vout = + V DC power supply -1V								
8/A2-	GND Control input ON/OFF (common to terminal 3/A2-)	Additional connection to be used only as GND for the control signal						
	Alarm output connector	r version with type "5" option (GRS-HA-5) (Overvoltage Category II o III)						
3/A2-	GND for power supply and control input ON/OFF	Ground for power supply and control input ON/OFF						
4/Us	+ Vdc power supply	Power supply GRS-H (Range from 6 to 32 V DC, Imax < 14 mA at 32V)						
4/05		GRS-H-90120AFAN63: Power supply GRS-H + Fan (Range from 20 to 27 V DC, Imax <150 mA at 24V with Fan active)						
5/A1+	+Vdc control input ON/OFF	Range: ON from 3 to 32Vdc, Imax <0,5 mA a 32V $$ OFF< 1,8V Input impedance 9,45 k $\Omega$						
6/A2-	GND Control input ON/OFF (common to terminal 3/A2-)	Additional connection to be used only as GND for the control signal						
7/AL		Solid state N.C. contact Imax = 50mA						
8/AL	Overtemperature alarm output	$Vmax = 30 Vdc/25Vac Z_closed < 15 \Omega Z_open > 1 M\Omega$						

The connections are also representative of 90-120A models For terminals and conductors to be used, see the table: "CLAMP AND CONDUCTOR CHARACTERISTICS TABLE" on page 14

# **DESCRIPTION OF CONNECTIONS**



		Description of terminal versions with type "A"input					
	Power terminals (common to all versions) (Overvoltage Category III)						
Rif.	Description	Notes					
1/L1	Line Connection						
2/T1	Load Connection						
		"Control connector" (Overvoltage Category II)					
3/A2	Control input ON/OEE in AC	Vac/Vdc input					
4/A1	Control input ON/OFF in AC	(Range 20 to 260Vac/Vdc, Imax < 8 mA) Overvoltage Category II					
	Alarm output connect	or version with type "5" option (GRS-HA-5) (Overvoltage Category II o III)					
5/AL		Solid state N.C. contact					
JAL		Imax = 150 mA					
	Overtemperature alarm output	Vmax = 30 Vdc/25Vac Z closed < 1 $\Omega$					
6AL		$Z_{open} > 1 M\Omega$					

The connections are also representative of 90-120A models For terminals and conductors to be used, see the table: "CLAMP AND CONDUCTOR CHARACTERISTICS TABLE" on page 14



#### LED STATUS DESCRIPTION

Note: Control LED is always present, Temp Alarm and Fault Alarm LEDs are optional

STATUS	LED Control (Green)	LED Temp Alarm (Yellow)	LED Fault Alarm/Out Alarm (Alarm:Red)
SCR OFF, no alarm	OFF	OFF	OFF
SCR ON, no alarm	ON	OFF	OFF
SCR ON, Alarm output active	ON	OFF	ON
Control signal active, SCR forced off for overtemperature protection	OFF	ON	OFF
Control signal active, SCR forced off for overtemperature protection, Alarm output active	OFF	ON	ON
SCR off, Alarm output active for interrupted load (alarm is stored, Status only possible with GRS-H with Type D input and options 1/2/3)	OFF	OFF	ON

#### Logic voltage output command



### THERMAL ALARM

# Models with thermal alarm



# ALARM LOAD INTERRUPTED

GRS-H with V DC command (Control type "D" with options)



#### **GRS-H** thermal protection



### Models with thermal alarm and FAN63 option



Single-phase connection



Three-phase Triangle or Star connection without neutral on two phases



(\*) Or relè output with Vac tension (Use GRS-H with comand input vac type A)

Connection example for GRS-H with VDC ("DD-0" type)







### TABLE OF TERMINALS AND CONDUCTORS

POWER TERMINALS Rigid/flexible / ferrule conductor cross section									
Nominal current of the load	15A	25A	30A	40A	50A	60A	75A	90A	120A
Contact area (WxD) screw type			,	8 mm 15	m 10,5 x 10,7 mm M5				1
Stripping length		11 mm 13 mm			13 mm				
1 Conductor section 2 Conductors section	1 x 2.5 mm <sup>2</sup> / 2 x 1.5 mm <sup>2</sup>		mm² / mm²	1 x 10 mm <sup>2</sup> / 2 x 6 mm <sup>2</sup>	1 x 16 mm <sup>2</sup> / 2 x 10 mm <sup>2</sup>		mm² / 6 mm²	35 mm²	1 x 50 mm <sup>2</sup> / 2 x 25 mm <sup>2</sup>
(minimum section)	1 x 14 AWG / 2 x 17 AWG	1 x 10 2 x 12		1 x 8 AWG / 2 x 10 AWG	1 x 6 AWG / 2 x 8 AWG	1 x 4 AWG / 2 x 6 AWG	1 x 3 AWG / 2 x 6 AWG	2 AWG	1 x 1/0 AWG / 2 x 3 AWG
Maximum allowed section	Maximum allowed section         1 x 25 mm² /2 x 16 mm²           1 x 3 AWG /2 x 6 AWG						/ 2 x 25 mm² i / 2 x 3 AWG		
Tightening torque					2,5-3 Nm (22-26,6lb-in)				

Note: Use 75°C (167°F) copper (CU), multi-stranded conductors

<b>CONTROL/SIGNAL TERMINALS</b> Rigid / flexible / cable lug conductor cross section					
1 Conductor section	1 x 0.2-0.75 mm² / 2 x 0.1-0.5 mm²				
2 Conductors section	1 x 24-18 AWG 2 x 27-20 AWG				
Stripping length / cable lug	1x 8-10 mm 2x 10-12 mm				
Nota: Usare conduttori in rame (CU) 60/75°C (140/167°F), rigidi o multifilari					

GROU	ND TERMINAL*
Contact area (WxD) screw type	9 x 9 mm M5
Tightening torque	1,5-2,5 Nm (13.3 lb-in – 22 lb-in)

- (\*) The screw terminals are only suitable for on-site wiring connection when the wire is equipped with a tube terminal with eyelet.
 It is possible to make ground connection using a copper bar suitably ground connected and fixed to the heatsink of more GRS-H.
 (WxD) = Width x depth

Nota:

For Canadian end-use applications only, an R/C VZCA/7 (or CSA-approved) surge protector is required to be installed in the end-use as shown below:

- Maximum clamping voltage 800V, for the control input of Type "D"/"DD" devices.

- Maximum clamping voltage 2500V, for control input of "A" type devices.

- Maximum clamping voltage 800V, for the auxiliary output of type "D"/"DD" and "A" devices.

#### **PROTECTION FUSES**

Type 1 and Type 2 coordination are ratings based on the level of protection and resilience provided during a high current fault. Device is designed to protect people and equipment during a short circuit fault,, but the differences between the two levels can be explained as follows: Type 1 : after a short circuit event it may be too damaged for further use.

Type 2 : after a short circuit event device will still be in working.

#### Protection co-ordination (Type 2)

Size device Fuse nominal Current		Model and fuse size (manufacturer Bussmann Div Cooper (UK) Ltd)	Fuse code (descr.)	Fuse holder accessory code (descr.)
15	16	FWC-16A10F 10x38	338470 (FUS-016)	
25,251	25	FWC-25A10F 10x38	338474 (FUS-025)	337132 (PF-10x38)
30,301	32	FWC-32A10F 10x38	338483 (FUS-032)	
40	40	FWP-40A14F 14x51	338147 (FUS-040)	
50 50		FWP-50A14F 14x51	338079 (FUS-051)	- 337131 (PF-14x51)
60	63	FWP-63A22F 22x58	338191 (FUS-063)	
75	80	FWP-80A22F 22x58	338199 (FUS-080)	337130 (PF-22x58)
90 100		FWP100A22F 22x58	338478 (FUS-100)	
120	125	170M1418 000-TN/80	338106 (FUS-100)	337092 (PF-DIN)

#### Protection co-ordination (Type 1 ) according to UL 508

The devices are suitable For Use On A Circuit Capable Of Delivering Not More Than 100,000 A rms Symmetrical Amperes, 600 Volts Maximum when Protected by UL Listed fuses with size and class as specified in the table below:

Size device	Fuse Class	Fuse Current Max Size [A]	Prospective short circuit current [kArms]
15 05 00	J	40	
15, 25 , 30	CC	30	
40		40	
251		80	
301		80	
50	7.	80	100
60	_ J	80	
75		80	
90		125	
120		125	

Use Fuses Only.

### GG FUSES

An electrical protection device known as a GG FUSE must be used to ensure protection against short-circuit of the electrical cable (see EN 60439-1, paragraph 7.5 Short-circuit protection and short-circuit withstand strength" and 7.6 "Switching devices and components installed in ASSEM-BLIES", or the equivalent paragraphs of standard EN 61439-1).

#### **PROTEZIONE CON MCB**

Protectio	n co-ordination (Type 2	) with Siemen		(MCB) mermai-magnet	c) 5514 series, cur	
Current size model (l <sup>2</sup> t)	1P MCB model (MCB Nominal current in A) at 230Vac *	Wire cross sectional area (mm <sup>2</sup> )	Minimum length ***of copper wire conductor (m)	2P MCB model (MCB Nominal current in A) at 400Vac **	Wire cross sectional area (mm2)	Minimum length ***of copper wire conductor (m)
GRS(-H)-15,25,30,40	5SY4110-5 (10)	1,0	6,0	5SY4210-5 (10)	1,0	6,0
(1800 A <sup>2</sup> s)		1,5	9,0		1,5	10,0
		2,5	14,0	1	2,5	14,0
	5SY4116-5 (16)	1,0	6,0	5SY4216-5 (16)	1,0	6,0
		1,5	9,0		1,5	10,0
		2,5	14,0		2,5	14,0
		4,0	15,0	1	4,0	25,0
	5SY4120-5 (20)	1,5	9,0	5SY4220-5 (20)	1,5	10,0
		2,5	15,0	1	2,5	21,0
		4,0	30,0		4,0	30,0
	5SY4125-5 (25)	2,5	18,0	5SY4225-5 (25)	2,5	18,0
		4,0	30,0	1	4,0	30,0
	5SY4132-5 (32)	2,5	21,0	5SY4232-5 (32)	2,5	36,0
		4,0	35,0		-	-
GRS(-H)- <b>25I</b> , <b>30I</b> , 50,	For MCBs smaller than	those indicated	in the lines below, there are	no section and length con	straints.	
60,75 (12800 A <sup>2</sup> s)	5SY4132-5 (32)	2,5	2,0		2,5	2,0
		4,0	4,0		4,0	4,0
		6,0	7,0		6,0	7,0
	5SY4140-5 (40)	4,0	4,0	5SY4240-5 (40)	4,0	4,0
		6,0	7,0		6,0	7,0
		10,0	10,0		10,0	10,0
	5SY4150-5 (50)	6,0	7,0	5SY4250-5 (50)	6,0	7,0
		10,0	10,0		10,0	10,0
		16,0	18,0		16,0	18,0
	5SY4163-5 (63)	6,0	7,0	5SY4263-5 (63)	6,0	7,0
		10,0	10,0	1	10,0	10,0
		16,0	18,0		16,0	18,0
GRS(-H)-90,120	For MCBs smaller than	those indicated	in the lines below, there are	no section and length con	straints	1
(11250 A <sup>2</sup> s)	5SY4132-5 (32)	2,5	2,0	5SY4232-5 (32)	2,5	2,0
		4,0	4,0		4,0	4,0
		6,0	7,0	-	6,0	7,0
	5SY4140-5 (40)	4,0	4,0	5SY4240-5 (40)	4,0	4,0
		6,0	7,0		6,0	7,0
		10,0	10,0	-	10,0	10,0
	5SY4150-5 (50)	6,0	7,0	5SY4250-5 (50)	6,0	7,0
		10,0	10,0		10,0	10,0
		16,0	18,0	1	16,0	18,0
	5SY4163-5 (63)	6,0	7,0	5SY4263-5 (63)	6,0	7,0
		10,0	10,0		10,0	10,0
		16,0	18,0	1	16,0	18,0

\* The sizing is valid for a 230Vac phase-neutral line with an assumed short-circuit current of 2,5KA

\*\* The sizing is valid for a 400Vac phase-to-phase line with an assumed short-circuit current of 5KA \*\*\* Between MCB and Load plus return path which goes back to the lines/neutral

Example, for a GRS-H-50- ..., with line voltage of 230Vac, controlled load of 45 A nominal, with a section of 6mm2 of cable, an MCB 5SY4150-5 (50 A) the minimum length of the cables is 7m (cable length is intended between MCB and load, including return).

#### FANS (for 90A/120A models only)

Model	Code	Туре	Supply
90A FAN60	363484	230 Vac 60mm x 60mm x 30mm for 90A models	Separate power supply
120A FAN60	363011	230Vac 80mm x 80mm x 38 mm for 120A models	Separate power supply
90A FAN61	363485	115Vac 60mm x 60mm x 30 mm for 90A models	Separate power supply
120A FAN61	363003	115Vac 80mm x 80mm x 38 mm for 120A models	Separate power supply
FAN62	363037	24 Vdc 60mm x 60mm x 25mm	Separate power supply
FAN63	363037	24 Vdc 60mm x 60mm x 25mm	Internally powered by GRS-H

# PERIODIC CLEANING

Every 6-12 months (depending on dust in the place where it is installed), blow a jet of compressed air downward through the cooling heatsink (on the opposite side of the fan).

In this way both the heat sink and the cooling fan are cleaned.

# IN THE EVENT OF OVERTEMPERATURE ALARM

If periodic cleaning does not eliminate the problem, perform the following operations:

- 1. Disconnect the fan cables from the terminal block (if present) or disconnect the fan connector from the GRS-H (FAN63).
- 2. Unscrew the screws securing the fan to the support brackets
- 3. Check the condition of the fan, clean it or replace it
- 4. Reassemble the fan

Caution: make sure that the arrow showing the direction of the air flow on the fan is pointing toward the heat sink







Use a Phillips screwdriver with a max. diameter of 3.5mm.













#### Notes:

(1) Available only for versions with type input D

(2) Available only for versions with type input D and Options (D-1, D-2, D-3, D-5). This option allows you to turn on the fan only when necessary, increasing its useful life.



#### Read the following warnings before installing, connecting or using the device:

- · follow instructions precisely when connecting the device.
- · always use cables that are suitable for the voltage and current levels indicated in the technical specifications.
- In applications with risk of damage to persons, machines or materials, you MUST install auxiliary alarm devices.
- It is advisable to verify frequently that the alarm device is functional even during the normal operation of the equipment.
- DO NOT operate the device in rooms with dangerous (inflammable or explosive) atmosphere.
- During continuous operation, the heat sink can reach up to 100°C, and stays at a high temperature even after the device is turned off due to thermal inertia; therefore, DO NOT touch it and avoid contact with electrical wires.
- · do not work on the power part without first disconnecting electrical power to the panel.
- do not remove the cover when the device is powered!

#### Installation:

- · correctly ground the device using the specific terminal.
- power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.
- · avoid dust, humidity, corrosive gases and heat sources.
- respect the installation distances between one device and another (to allow for dissipation of generated heat).
- to keep air in movement, we advise you to install a fan near the GRS-H group in the electrical panel containing the GRS-H.
- respect the indicated dissipation curves

#### Maintenance:

at regular intervals, check operation of the cooling fans and clean all air ventilation filters.

- repairs must be done out only by trained and specialized personnel. Cut power to the device before accessing internal parts.
- do not clean the box with solvents derived from hydrocarbons (trichloroethylene, gasoline, etc.). Using such solvents will compromise the device's mechanical reliability. Use a clean cloth moistened with ethyl alcohol or water to clean external parts in plastic.

#### Service:

GEFRAN has a service department. The warranty excludes defects caused by any use not conforming to these instructions.

GEFRAN spa reserves the right to make aesthetic or functional changes at any time and without notice.

CE	This device conforms to European Union Directive 2014/30/EU and 2014/35/EU as amended with reference to generic standards: <b>EN 61000-6-2</b> (iammunity in industrial environment) <b>EN 61000-6-4</b> (emission in industrial environment) - <b>EN 61010-1</b> (safety regulations).
CUL US LISTED	cULus listed, Conformity UL508 - File: E243386
ERC	EAC, Conformity TC RU C-IT.АЛ32.В.00422
SCCR RMS SYM 100KA / 600V	Short Circuit Current Rating 100KA / 600V according to UL 508



GEFRAN spa via Sebina, 74 - 25050 Provaglio d'Iseo (BS) Tel. 03098881 - fax 0309839063 - Internet: http://www.gefran.it